

Copy your MP3 files into the root directory of your SD card from your computer. File names may be up to 20 characters. You may use numbers, letters, and spaces only.

Insert the SD card in your card reader and click the "Refresh SD Card" button to display the MP3 files on your card. Create your playlists as instructed below. Don't forget to save them. You may have up to 10 lists (1 thru 0). All files must be mp3 format with the .mp3 extension in lower case. Itunes encoded files will not work properly.



You may also double click on a file to move it to the playlist.

Select the current playlist with the up/down buttons and type a playlist name in the box.

You may also print the current playlist with the print button.

← Open the selected Playlist

← Save the selected Playlist

← Delete the selected Playlist

← Move selected file up the list

← Move selected file down the list

← Remove selected file from list

← Clear the selected list

Click the advanced button to enter advance options for the selected track.