

General Operation

After making your playlists (see "playlist instructions") insert your SD Card into the player. Select the desired playlist with the playlist selector switch (1 thru 0). The led will turn off momentarily while the player loads the list after which the led will be green. This indicates that you are on the first track in the list. All other tracks the led will be red. (flashing while playing). To reset to beginning of the playlist, press and hold the reset button until it turns green. A quick press of the reset button will emulate the play/pause button (remote # 1).

If the led flashes red and green alternately, this indicates an error. Check to be sure the card is inserted properly. If you still get the error then you are either set to an invalid playlist number or have an invalid track name. It is a good idea to check all playlists in the player after editing them to be safe.

Volume Presets

You may adjust the overall volume of any track with the player itself. Once adjusted it will be permanent unless it is re-adjusted. To do this.... While the track is playing, press and keep holding the reset button until it goes off (4-5 sec.) When you release the button the led will be green and the volume will change to the setting on the playlist selector. Use the buttons on the selector to change the volume while listening to it. To save the track volume, press and hold the reset button until the led turns off. Release the button and use the selector to return to the playlist that you were on. When the led turns on green again it will be set. If it flashes an error setting, you are not back to the original playlist and must adjust the selector switch until the led turns steady green.



Remote Functions

The # I button will pause and unpauses the current track. If a track has finished it will auto-pause and cue to the next track. The # II button cues to the next track, if a track is playing the music will fade then cue. You may change the functions of this button in the advanced screen if desired. Pressing I & II simultaneously will cue back one track. The ankle strap is used for pause - unpauses only. Strap the magnet to one ankle and the transmitter to the other. They should be positioned so that when your feet are together the magnet touches the transmitter which will trigger button # I. You only need to keep your feet together for a half second.

The **Volume** buttons will adjust the volume up or down by pressing and holding them. Press # III for more volume and # IV for less volume. Pressing both will reset the volume to the default.

